


Zinwell ZWA-G220

Mudança de Senha SSH

- 1) Passo 1: utilize o SSH e conecte ao G220. Utilize usuário root e senha zplus12320400
- 2) Passo 2: execute o comando no SSH “flash set ROOT_PASSWORD YourPassword” e pressione enter
- 3) Passo 3: execute o comando no SSH “reboot”



```
PuTTY (inactive)
連線(C) 編輯(E) 檢視(V) 視窗(W) 選項(O) 說明(H)
login as: root
root@192.168.2.254's password: ***
Access denied
root@192.168.2.254's password: *****

BusyBox v1.00-pre9 (2006.06.26-00:14+0000) Built-in shell (ash)
Enter 'help' for a list of built-in commands.

# flash set ROOT_PASSWORD 1234567890abcd
# reboot
```

A senha deve ter no máximo 14 caracteres.

A senha pode ser restaurado para o padrão (zplus12320400) efetuando um reset de hardware.