


# Zinwell ZPlus-G120

## Mudança de Senha SSH

- 1) Passo 1: utilize o SSH e conecte ao G120. Utilize usuario **root** e senha **qwert**
- 2) Passo 2: execute o comando no SSH  
“flash set ROOT\_PASSWORD YourPassword”  
e pressione enter
- 3) Passo 3: execute o comando no SSH “reboot”



```
PiTTY (inactive)
連線(C) 編輯(E) 檢視(V) 視窗(W) 選項(O) 說明(H)
login as: root
root@192.168.2.254's password: ***
Access denied
root@192.168.2.254's password: *****
BusyBox v1.00-pre9 (2006.06.26-00:14+0000) Built-in shell (ash)
Enter 'help' for a list of built-in commands.
# flash set ROOT_PASSWORD 1234567890abcd
# reboot
```

A senha deve ter no máximo 14 caracteres.

A senha pode ser restaurado para o padrão (qwert) efetuando um reset de hardware.